

Guides for Installing Transmission Cover & Gasket (Ford 9N)

By Del Huebner

These studs were made from 7/16" x 2" bolts by removing the head with a chop saw and beveling the top to smooth them out:



Screw them into casing. Install gasket & cover. The studs hold everything in place (studs are only finger tight). Remove studs and install the bolts:



The same 6 studs can be used to install the steering sector and gasket:



*Best internet source
of information and help
for old Ford tractors.*

www.ntractorclub.com