

Figure 13 - Anchor Bracket Assemblies

FIG. 13	PART NO.	NAME AND DESCRIPTION	QTY REQ
		Group 1-9—ANCHOR BRACKET ASSEMBLIES (Models 14-1, 14-2, 14-9, 14-10, 14-15, and 14-16)	
1	*141567 141561	BRACKET ASSEMBLY R. H. Anchor Model 14-1,2 only BRACKET ASSEMBLY, L. H. Anchor	1 1
2 -	230044	PIN, Anchor LOCKWASHER, 5/8" NUT, 5/8" - 18 Hex. Anchor Pin to Bracket	1
- 3 4 5	142210 2N-574 2N-575	NUT, 5/8" - 18 Hex. Michael Fin to Blacket CHAIN ASSEMBLY PIN, Linch. RING, Linch Pin	1 1 1 1
6 7 8 9	141186 230044	BRACKET and BALL ASSEMBLY, R. H. Anchor PIN, Anchor LOCKWASHER, 5/8" NUT, 5/8" - 18 Hex. Anchor Pin to Bracket	1 1 1
10 11 12 13	142210 2N-574 2N-575 141569	CHAIN ASSEMBLY. PIN, Linch	1 1 1 1
14 15 16		BOLT, 5/8" - 18 x 6-1/2" Carr. LOCKWASHER, 5/8" NUT, 5/8" - 18 Hex. Clip and R. H. Anchor Bracket to Axle	1
 See		BOLT, 5/8" - 11 x 6-1/2" Hex. Hd. (Use on 2N, 9N and early 8N Tractors to fasten Mower R. H. Anchor Bracket to Axle	1
Fig.	230042	LINK, Stabilizer	1
		*Use on Model 14-1 Prior to Serial No. 27282 *Use on Model 14-2 Prior to Serial No. 27535	




FIG.	DADOTATO		QTY. REQ.	
		Group 1-3—BELT HOUSING SUPPORT (Models 14-1, 14-2, 14-9, and 14-10)	4-1, 2	4-9, 10
1	141375	SUPPORT ASSEMBLY, Belt Housing	1	1 1
2 -	141377	listed below: *CLIP, Tie Rod	1	1
3	141385	NUT, 1/4" - 28 Hex. TUBE ASSEMBLY Belt Housing Samuel	2	2
4 5 6 7 8 9 10 11 12	141387 141393 141391 141396 141394 141194 141651 141653	Consists of Tube which is not serviced separately plus Spacer listed below: SPACER, 7/8" I.D. x 1-1/4" O.D. x .083 Plug KEY, Tube to Housing. BUMPER, Belt Housing Support Rubber BUSHING, Belt Housing Support Rubber. WASHER, Belt Housing Bushing Retainer STUD LOCKWASHER, 3/4" Support to Belt Housing. NUT, 3/4" - 16 Hex. TIE ROD ASSEMBLY, Safety TIE ROD ASSEMBLY, Safety Consists of Rod which is not serviced separately plus items listed below: HANDLE, Tie Rod. NUT, 1/2" - 13 Hex Handle Stop.	2 1 2 2 1 2 2 1 - 1	2 1 2 2 2 2 1 2 2 1
		*Supports are being furnished with the Clip welded on Steel Supports and bolted on Iron Supports.	1	1

FIG. 12	PART NO.	NAME AND DESCRIPTION	QTY. REG		Q.	
		Group 1-8—CUTTER BAR, KNIFE AND OUTER SHOE ASSEMBLIES	14-1-9	14-2-10	14-15	14-16
-	142636 142637	CUTTER BAR and OUTER SHOE ASSEMBLY, 6'	-	-	1 -	- 1
-	141004	CUTTER BAR and OUTER SHOE ASSEMBLY, 7'	-	1	-	-
1 -	140474 140475	BAR, Cutter, 6'	1 -	- 1	1 -	- 1
2 3 4 5	142726 141008 141021 141015	CLIP, Knife - Plain. CLIP, Knife - Inner. PLATE, Wear. SHIM, .050.	5 1 6 6	6 1 7 7	5 1 6 6	6 1 7 7
6 - 7	141009 140470 141013 140472	GUARD ASSEMBLY, Rock (Model 14-15A-Qty. of 22 or 26) GUARD ASSEMBLY, Plain	22	26 - 1	22 - 1	26 -
8	142570 141012	items listed below:	23	27	23	27
9	141012	RIVET, Ledger Plate to Rock. BOLT, 7/16" - 20 x 1-1/2" Plow Plain Clip to Cutter NUT, 7/16" - 20 Hex. Bar and Rock Guard	10	27 12	23 10	12
11 11		BOLT, 7/16" - 20 x 1-1/4" Plow Rock Guard to Cutter NUT, 7/16" - 20 Hex.	9	11	9	11
12 13	targarii Ertexalig	BOLT, 7/16" - 20 x 1-3/4" Plow Inner Clip to Cutter NUT, 7/16" - 20 Hex. Bar and Rock Guard	2	2	2	2
14 15 16	141044	BOLT, 7/16" - 20 x 1-1/4" Plow, Rib Neck LOCKWASHER, 7/16" Shakeproof NUT, 7/16" - 20 Hex.	2	2	2	2
17	143570	SHOE ASSEMBLY, Outer	1	1	1	1
18	142571 141019	items listed below: PLATE, Ledger	1	1	1	1
	141020 143566 143567	RIVET, .210 x 1-3/16" Shoe Assy Not Shown	1	1	1	1 1
19 20 21	141022	SOLE, Outer Shoe (Welded Assembly)	1	1	-	-
22		LOCKWASHER, 7/16" Outer Shoe to Cutter Bar NUT, 7/16" - 20 Hex. BOLT, 7/16" - 14 x 2-1/4" Carr.	2	2	2	2
		LOCKWASHER, 7/16" NUT, 7/16" - 14 Hex. Sole to Outer Shoe Assy	-	-	1	1
23 24 25		BOLT, 3/8" - 16 x 1-1/4" Carr. LOCKWASHER, 3/8" NUT, 3/8" - 16 Hex.	1	1	-	-
	142644	SWATHBOARD and FITTING ASSEMBLY	1	1	-	-
26 27 28 29 30 31	142645 *140443 141246 141327	SWATHBOARD (Riveted Assembly) SPRING, Swathboard BOLT, 1/2" - 13 x 2-3/4" Carr. WASHER, 21/32" I.D. x 1-5/8" O.D. Flat NUT, 1/2" - 13 Hex. Slotted COTTER PIN, 1/8" x 1" Swathboard and Spring to Outer Shoe	1 1 1 1 1	1 1 1 1 1	- 1 2 1	- 1 2 1
32	142652	*When replacing spring on units prior to Serial Numbers 14-1-3552, and 14-2-4016, order 140443 Spring plus 1-1/2"-13 x 2-1/2" Sq Hd. Bolt, 1-141327 Washer and 1-1/2"-13 - Hex. Slotted Nut, and 1-1/8" x 1 Cotter Pin. **Www.ntractorclub.com**	2			

FIG.	PART NO.	NAME AND DESCRIPTION	QTY. REC			EQ.
		Group 1-8—CUTTER BAR, KNIFE AND OUTER	2	10		
E.		SHOE ASSEMBLIES (Cont'd)	14-1,	6	14-15	4-16
	BURNET TO	STIGE ASSEMBLIES (CONT d)	4-	14-9,	4-	14-
33		BOLT, 5/16" - 18 x 1-1/4" Carr. γ	1			
34		BOLT, 5/16" - 18 x 2-1/2" Carr.	1			
35	A Part I I I I I	WASHER, 5/16" Flat LOCKWASHER, 5/16" to Swathboard	2			
36	A 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Eccit Wildingto, 0/10	2			2
37	The Part of the State of the St	NUT, 5/16" - 18 Hex.	2	2	2	2
38	142651	STICK, Grass (Not part of 142644)	1	1	1	1
39	141107	KNIFE ASSEMBLY, 6' Underserrated	1		1	_
39A	142668	KNIFE ASSEMBLY, 6' Underserrated	95.0	-	1	6_1
	141108	KNIFE ASSEMBLY, 7' Underserrated	1	1	_	-
	142669	KNIFE ASSEMBLY, 7' Underserrated	-	-	-	1
11	141137	KNIFE ASSEMBLY, 6' Plain	1	-	-	-
	142713	KNIFE ASSEMBLY, 6' Plain	-	-	1	-
	141138 142714	KNIFE ASSEMBLY, 7' Plain	-	1	-	-
	142/14	KNIFE ASSEMBLY, 7' Plain	-	-	-	1
40	142670		1- 11	Engl		0 m
40A	141109	HEAD, Knife	-	1	1	1
	141121	HEAD, Knife RIVET, Knife Head to Back .210" x .81"	1	1	3	-
	141114	RIVET, Knife Head to Back .210 x .68"	2	2	100	3
41	141110	REINFORCEMENT, Knife Head	1	1	_	
	141111	BACK, Knife, 6'	1	-	1	1
	141112	BACK, Knife, 7'	-	1	1	1
	141113	SECTION, Underserrated Knife (Optional)	24	28	24	28
42	141682	SECTION, Plain Knife	24	28	24	AVVICURE OF
	141197	SECTION, Knife, Heavy Plain (.109) (Optional)	24	28	24	28
	141198	SECTION, Knife, Heavy Serrated (.109) (Optional)	24	28	24	28
43	141115	RIVET, Knife Section to Back (.210 x 1.06)	5	5	-	12
44 44A	141121 142673	RIVET, Knife Section to Head and Reinforcement (.210 x .81).	6	6	3	3
44A 45	141116	RIVET, Knife Section to Head (.210 x 15/16")	-	-	7	7
	THE THE PARTY OF T	RIVET, Knife Section to Back (.210 x .56)	37	45	41	49
46	141117	SOCKET ASSEMBIY, Front Ball	1	1	1	_
		Consists of Socket which is not serviced separately plus				
		Fitting listed below:				- 4
47		FITTING, Lube, 1/4" - 28 x 3/4", 45 ⁰	1	1	_	-
48	141119	SOCKET ASSEMBLY, Rear Ball	1	1	-	-
		Consists of Socket which is not serviced separately plus				1000
49		Fitting listed below:				
		FITTING, Lube, $1/4'' - 28 \times 3/4''$, 45^0	As	1 As	-	-
50	141681	SHIM, 1" x 2-1/4" Flat	Req.		-	_
51		BOLT, 1/2" - 20 x 1-5/8" Hex.	1	1	-	-
52		BOLT, 1/2" - 20 x 2-1/4" Hex. Ball Socket to Knife Head	1	1	_	
53 54		200111110111111, 1/2	2	2	-	-
34		NUT, 1/2" - 20 Hex.	2	2	-	-
	145642	RIVET ASSORTMENT - Repair		100		THE .
	200	Consists of		241		118
	141114	RIVET, .210" x .68"	2	2	2	2
	141115	RIVET, .210" x 1.06"	6	6	6	6
	141116	RIVE T, .210" x .56"	49	49	49	49
	141121	RIVE T, .210" x .81"	6	6	6	6
	142673	RIVET, .210" x 15/16"	7	7	7	7
		www.nuactorciub.com				1

Figure 12 - Cutter Bar, Knife and Outer Shoe Assemblies

FIG 9	PART NO.	NAME AND DESCRIPTION	QTY. REQ.		
	2 2	Group 1-5—DRAGBAR AND HINGE ASSEMBLIES (Models 14-1, 14-2, 14-9, 14-10, 14-15,	4-1,2	9,10	14-15,16
		and 14-16)	4-1	14-6	4-1
1	141149	HINGE ASSEMBLY	1	1	1
2	141000	FITTING, Lube, 1/4" - 28 x 1/2" Str	3	3	3
3	141666	LEVER, Tilt	1	1	1
-	141658	YOKE ASSEMBLY, Tilt Lever	1	1	1
4	141659	YOKE	1	1	1
6	141660	SPACER, 5/8" I.D. x 7/8" O.D. x .640 Tube	1	1	1
7 8		LOCKWASHER, 5/8" WASHER, 5/8" Flat Tilt Lever Yoke	1	1	1
-	141662	PIN and CHAIN ASSEMBLY, Tilt Link Anchor	1	1	-
-	141663	PIN, Anchor	1	1	(88)
-	142210	CHAIN ASSEMBLY	1	1	
	SAUDINES - 19	COTTER PIN, 1/8" x 1"	1	1	-
-	141661	PIN, Hair - Anchor Pin to Tilt Link	1	1	
9 10 11		BOLT, 1/2" - 20 x 1-1/2 Hex. Hd. LOCKWASHER, 1/2" NUT, 1/2" - 20 Hex. Yoke to Tilt Link			1
12 13 14		BOLT, 5/8" - 18 x 2-1/2" Hex. Hd. LOCKWASHER, 5/8" NUT, 5/8" - 18 Hex.	1	1	1
15 16 17		BOLT, 5/8" - 18 x 3-1/2" Hex. Hd. LOCKWASHER, 5/8" NUT, 5/8" - 18 Hex.	1	1	- '
17A 18	142654 142667	DRAGBAR (Welded Assembly)	- 08	1	1
	141176	DRAGBAR and EYE ASSEMBLY	1	1	1
18A	141153	Consists of:			1
19	141422	DRAGBAR (Welded Assembly)	1 1	1	-
	*141050	EYE, Dragbar	1	_	
	*141051	SPACER, Dragbar Yoke	1	4	_
20 21		BOLT, 5/8" - 18 x 1-5/8" Hex. Hd.	2	2	-110
22	141423	LOCKWASHER, 5/8" External SPACER, 5/8" I.D. x 1 O.D. x 3/4 Tube	4	4	-
23	141426		2	2	-
24 25	141426	WASHER, .115 I.D. x 2.25 O.D. x 1/4" Flat NUT, 1-1/8" - 12 Castle COTTER PIN, 3/16" x 1-1/2" Dragbar Retaining.	1	1	1
26	141395	BUSHING, Dragbar Eye	0	0	
	*141388	ANCHOR PIN, Dragbar (Welded Assembly)	2 1	2	-
27	†141683	ANCHOR PIN, Dragbar (Welded Assembly)	1	1	-
7		*Used on Model 14-1 prior to Serial No. 1095 and Model 14-2 prior to Serial No. 1062.	2 4		
		†Effective with Serial No. 1095 for 14-1 and Serial No. 1062 for 14-2.			

FIG.	PART NO.	NAME AND DESCRIPTION	Q	TY. R	EQ.
2	2 2	Group 1-5—DRAGBAR AND HINGE ASSEMBLIES (Models 14-1, 14-2, 14-9, 14-10, 14-15, and 14-16) (Cont'd)	14-1,2	14-9,10	14-15,16
28	†141689 *	WASHER, 1" I.D 3" O.D. Flat)	1	1	-
29	†	WASHER, 3/4" Flat WASHER, 7/8" Flat WASHER 7/8" I D 3" O D Flat Dragbar Anchor Pin	1	1	-
30 30A	*141390	WASHER, 7/8" I.D3" O.D. Flat NUT, 7/8" - 14 Hex. Slotted COTTER PIN, 1/8" - 1-1/4"	1 1 1	1 1	-
See Fig. 5 31	142620 142699	CUP, Dragbar, Ball, Neoprene	-	-	1 1
32 33 34		BOLT, 3/8" - 24 x 2 Hex. Hd. LOCKWASHER, 3/8" NUT, 3/8" - 24 Hex.	-	-	4
	142662 141405	LEVER ASSEMBLY, Hinge Lift	-	-	1
35	141170	LEVER ASSEMBLY, Hinge Lift LEVER ASSEMBLY, Hinge Lift Consists of Lever which is not serviced separately plus items listed below:	1 -	1	-
36	149004	FITTING, Lube, 1/4" - 28 x 1/2" Str	1	1	1
	142664 142665	LINER BUSHING. 11/16" x 1" x 5/8" Tube	-	100791	1 1
37	141413 141178	SHAFT ASSEMBLY, Hinge Lift LeverSHAFT ASSEMBLY, Hinge Lift Lever	1 -	1	1
38	141415 141196	Consists of Shaft which is not serviced separately plus Snap Ring listed below: SNAP RING	1	-	-11
 39	141190	SNAP RING COTTER PIN, 3/16" x 1-1/2" WASHER, 1-3/16" Flat LOCKWASHER, 1" Shaft Retaining	1 -	1	1 - 1
40	141159	NUT, 1"- 14 Hex.	-	1	1
41	141381	CLEVIS ASSEMBLY, Chain	1	1	-
42 43		PIN, 1/2" x 1-15/16" Clevis	1	1	-
44	141411	LINK, Chain	1 1	1	-
45	141412	HOOK, Balance Spring	1	1	-
46 47	141408 141409	LINK, LiftYOKE	. 1	1	1
48 49	141427	NUT, 1/2" - 20 Hex. Lift Link	2	2	2
50		COTTER PIN, 1/8" x 1 and Link to Lever	2	2	-
	142666	BOLT, 1/2" - 20 x 1-5/8" Hex. Hd. SPACER, .508 I.D. x .743 O.D. x .570 Tube LOCKWASHER, 1/2" Lift Link Yoke to Hinge Lift Lever and Inner Shoe		SET SE	
	- i	NUT, 1/2" - 20 Hex. Jam Lift Lever *Used on Model 14-1 prior to Serial No. 1095 and Model 14-2	-	-	2
		prior to Serial No. 1062. † Effective with Serial No. 1095 for 14-1 and Serial No. 1062 for 14-2. **www.ntractorclub.com**			

MODELS 14-1, 14-2, 14-9, 14-10, 14-15 and 14-16

FIG.	PART NO.	NAME AND DESCRIPTI	ON	QTY. REQ.			
51	141032	Group 1-5—DRAGBAR AND HIN (Models 14-1, 14-2, 1 and 14-16) (Cont'd)	14-9, 14-10, 14-15,	14-1,2	14-9,10	14-15,16	
	142639	LEVER, Lift		1	1	-	
52 53 54 55 56	141033	BOLT, 5/8" - 18 x 2 Hex. Hd. SPACER, 5/8" I.D. x 7/8" O.D. x .54 Tube WASHER, 5/8" Flat LOCKWASHER, 5/8" NUT, 5/8" - 18 Hex.		1	1	1	




Figure 9 - Dragbar and Hinge Assemblies

www.ntractorclub.com

FIG.	PART NO.	NAME AND DESCRIPTION	QTY. REQ.
		Group 1-4—DRAWBAR AND LIFT LINKAGE ASSEMBLIES (Models 14-1, 14-2, 14-9, and 14-10) (Cont'd)	
11	141378	PLATE - Drawbar to Support	1
12		BOLT, 5/8" - 18 x 3" Hex. Hd.)	2
13	141140	NUT, 5/8" - 18 Hex. Prawbar to Support	4
14	141142	BLOCK, Rubber	1
16	Trebus P.	BOLT, 5/8" - 18 x 3-1/2" Hex Hd. WASHER, 5/8" Flat NUT, 5/8" - 18 Hex. Block to Drawbar	
17		WASHER, 5/8" Flat Block to Drawbar Block to Drawbar	1
18	141522	BRACKET, Lift Lever	
19	141523	U-BOLT, 7/16" - 20	1
20		LOCKWASHER, 7/16" Bracket to Drawbar	2
21	1 7 9	NUT, 7/16" - 20 Hex.	4
22	141508	LEVER ASSEMBLY, Lift	1
		Consists of Lever which is not serviced separately plus Fitting listed below:	
23		FITTING, Lube 1/4" - 28 x 1/2" Str	1
24	141519	SHAFT ASSEMBLY, Lift Lever	1
25	141415	SNAP RING - Lever Retaining	1
26		COTTER PIN, 3/16" x 1-1/2" - Shaft to Bracket	1
27	141510	SHEAVE ASSEMBLY, Lift Chain	1
28	141512	BUSHING, 3/4" x 7/8" x 1-1/2" Oilite	1
29	141513	SHAFT ASSEMBLY, Lift Chain Sheave	1
E 143		Consists of Shaft which is not serviced separately plus Snap Ring listed below:	
30	141515	GNAD DING	3
31	111010	COTTER PIN, 3/16" x 1-1/2" Sheave Retaining	1
32	141516	CHAIN ASSEMBLY, Lift	1
		Consists of Chain which is not serviced separately plus items listed below:	1
33	141518	ноок	1
34	141381	CLEVIS ASSEMBLY, Lift Chain	î
35	Territories	PIN, 1/2" x 1-15/16" Clevis	1
36		COTTER PIN, 1/8" x 1" - Pin to Clevis	1
37	230042	LINK, Stabilizer	î




Figure 8 - Drawbar and Lift Linkage Assemblies

FIG.	PART NO.	NAME AND DESCRIPTION	QTY. REQ.
		Group 1-4—DRAWBAR AND LIFT LINKAGE ASSEMBLIES (Models 14-1, 14-2, 14-9, and 14-10)	TIE Q.
1 2 3 4 5 6 7 8 9	141501 141164 141381 110521 110522	DRAWBAR (Welded Assembly) CHAIN, Safety (Welded Assembly) CLE VIS ASSEMBLY, Safety Chain Consists of Clevis which is not serviced separately plus items listed below: PIN, 1/2" x 1-15/16" Clevis COTTER PIN, 1/8" x 1" - Pin to Clevis PLATE, Adjusting Rack (Welded Assembly) PLATE, Adjusting Rack BOLT, 7/16" - 20 x 1-3/4" Carr LOCKWASHER, 7/16" Adjusting Rack Plates to Tractor Upper Link	1 1 1 1 1 1 1 1 2

FIG.	PART NO.	NAME AND DESCRIPTION	NAME AND DESCRIPTION QTY. R		
		Group 1-7—INNER SHOE ASSEMBLY (Cont'd)	4-1, 2	14-9, 10	14-15, 16
	141158	PIN, Hinge	-	2	2
5	141199	WASHER, 1-3/16" Flat		-	-
6	111100	LOCKWASHER, 1" Hinge Pin to Hinge	-	2	2
7	141159	NUT, 1"-14 Hex .			
8	141029	GUIDE ASSEMBLY, Front Knife	1	1	-1
9		FITTING, Lube, 1/4" - 28 x 1/2" Str	-1	1	1
	18000		As	As	As
10	141031	SHIM, Front Knife Guide	Req.	Req.	Req.
11		BOLT, 7/16" - 20 x 1-1/2" Carr. Front Knife Guide to			
12		LOCKWASHER, 7/16" Inner Shoe	2	2	2
13		NUT, 7/16" - 20 Hex.			
14	142640	GUIDE ASSEMBLY, Rear Knife	-		1
	141034	GUIDE ASSEMBLY, Rear Knife	1	1	-
	111001	Consists of Guide which is not serviced separately plus Fitting listed below:		22.	
15		FITTING, Lube, 1/4" - 28 x 1/2" Str	1	1	1
16	141037	SHIM, Rear Knife Guide, 1-1/4" x 9-3/8" Flat	2	2	-
17	141036	PLATE, Inner Wear	1	1	-
17A	142642	PLATE, Inner Wear	-	-	1
17B	142643	PLATE, Inner Wear	-	-	1
			As	As	As
18	141038	SHIM, 1-1/4" x 9-3/8" Flat	Req,	Req.	Req.
19		BOLT, 5/8" - 18 x 2-1/2" Carr.	2	2	2
20		BOLT, 5/8" - 18 x 1-3/4" Carr. Rear Knife Guide and Cutter	1 3	1 3	1 3
21		LOCKWASHER, 5/8" Bar to Inner Shoe	3	3	3
22		NUT, 5/8" - 18 Hex.	1 "		1 "
23	141675	SOLE, Inner Shoe (Welded Assembly)	1	1	1
24	141010	BOLT, 7/16" - 20 x 1-1/2" Hex. Hd.			
25		LOCKWASHER, 7/16" Sole to Inner Shoe	1	1	1
26		NUT, 7/16" - 20 Hex.			
27		BOLT, 1/2" - 20 x 1-1/4" Hex. Hd.			1 2000
28	W. Carlotte	LOCKWASHER, 1/2" Sole to Inner Shoe	1	1	1
29	z. (1865).	NUT, 1/2" - 20 Hex.			100
30	141655	ROD, Grass	1	1	1
31		BOLT, 7/16" - 20 x 1-1/2" Carr.			
32		WAGIND # /100 FILE	1.	1	1
33		LOCKWASHER, 7/16"	1	1	1
34		NUT, 7/16" - 20 Hex, ntractore ub.com			1




Figure 11 - Inner Shoe Assembly

FIG. 11	PART NO.	T NO. NAME AND DESCRIPTION		QTY. REQ.		
		Group 1-7-INNER SHOE ASSEMBLY	1, 2	9, 10	15, 16	
_	141026	CHOP ACCESSES	14-	14-	14-	
1	141156	SHOE ASSEMBLY, Inner (Riveted)	1	-,	-	
		SHOE ASSEMBLY, Inner (Riveted) Consists of Shoe which is not serviced separately plus items	-11	1	1	
		risted below:		1 N= =		
2 3	142572	PLATE, Inner Shoe Ledger	1	1	1	
-		RIVET, 3/16" x 5/8" - Plate to Shoe FITTING, Lube, 1/4" - 28 x 3/4", 45° FITTING, Lube, 1/4" - 28 x 1/2" Str	4	4	4	
-		FITTING, Lube, 1/4" - 28 x 3/4", 45" FITTING, Lube, 1/4" - 28 x 1/2" Str	1	1	1	
-	141039		1	1	1	
	111003	PIN ASSEMBLY, Hinge	2	-	-	
-	141041	SNAP RING				
-		COTTER PIN, 3/16" x 1-1/2" - Pin to Hinge	2	-	-	
	18 T	www.ntractorclub.com	4			

Group 1—DEARBORN REAR ATTACHED MOWERS

Models 14-1, 14-2, 14-9, and 14-10

FIG.	PART NO.	NAME AND DESCRIPTION	QTY. REQ.
10	Basel I	Group 1-1—MAIN DRIVE (Models 14-1, 14-2, 14-9, 14-10)	
	nd en a de la	NOTE: Rear attached Mowers are built using both Blood Bros. and Spicer Universal Joint Assemblies. In servicing these Universal Joint Assemblies it is necessary to order Blood Bros. parts if the Mower has a Blood Bros. Universal Joint Assembly or Spicer parts if the Mower has a Spicer Universal Joint Assembly. Blood Bros. parts are not interchangeable with Spicer parts and vice-versa.	日本
1	141210	UNIVERSAL JOINT ASSEMBLY, Tractor End	1
2	141212	YOKE, Clamp (Spicer)	1
_	141213	YOKE, Sleeve (Spicer)	1
2	141204	BEARING and JOURNAL ASSEMBLY (Service Kit) (Spicer)	50
		Consists of a Center Cross or Journal which is not serviced separately plus items listed below:	
3	140055	GASKET	4
4	140331	RETAINER	4
5	140059	BEARING, U. Joint	4
6	140277	SNAP RING	4
7	141135	YOKE, Clamp (Blood Bros.)	1
8	141136	YOKE, Sleeve (Blood Bros.)	1
9	141132	BEARING and JOURNAL ASSEMBLY (Service Kit) (Blood Bros.)	1
1191		Consists of a Center Cross or Journal which is not serviced separately plus items listed below:	
10	1 1 1 1 1 1 1 1	FITTING, Lube, 1/4" - 28 x 25/32", 90°	1
11	143538	WASHER, Cork	4
12	142787	RETAINER	4
13	142788	BEARING, U. Joint	4
14	142789	SNAP RING	4
15		BOLT, 1/2" - 20 x 1-3/4" Hex. Hd Front Universal Joint to P.T.O	1
16		FITTING, Lube, 1/4" - 28 x 1/2" Str U Joint	1
17	141206	SHAFT, Drive	1
18	141232	WASHER, Front Universal Joint Felt	1
19	141231	WASHER, Front Universal Joint Felt Retaining Split	2
20	141233	CAP, Front Universal Joint Felt Retaining Washer (Service Kit) (Blood Bros.)	1
21	Larre .	UNIVERSAL JOINT ASSEMBLY, Mower End (Blood Bros.)	1
22	141131	YOKE and SHAFT (Welded Assembly)	1
23	141133	YOKE, Plain	1
9	141132	BEARING and JOURNAL ASSEMBLY (Blood Bros.) Consists of a Center Cross or Journal which is not serviced separately	1
10	and and	plus items listed below: FITTING, Lube, 1/4" - 28 x 25/32", 90°	1
10	140500	FITTING, Lube, 1/4" - 28 X 25/3Z", 90	
11	143538	WASHER, Cork	4
12	142787	RETAINER	4
13	142788	BEARING, U. Joint	4
14	142789	SNAP RING	4
	141202	UNIVERSAL JOINT ASSEMBLY, Mower End (Spicer)	
and the last of th	141202	Consists of: YOKE and SHAFT (Welded Assembly)	1
	141203		1
	141205	YOKE, Universal Joint End	1

MODELS 14-1, 14-2, 14-9 and 14-10

210	PART NO.	NAME AND DESCRIPTION	QT
		Group 1-1—MAIN DRIVE (Models 14-1, 14-2,	RE
100		14 9 14 10) (6 st.)	
2	141204	14-9, 14-10) (Cont'd)	
3	140055	BEARING and JOURNAL ASSEMBLY (Service Kit) (Spicer) Consists of a Center Cross or Journal which is not serviced separately plus items listed below:	1
4	140331	GASKETRETAINER	4
5	140059	RETAINER BEARING, U. Joint	4
6	140277	BEARING, U. Joint	4
24 25		SET SCREW, 3/8" - 16 Rear Universal Joint to Drive Shaft	4
26	142574	HOUSING ASSEMBLY Booming	1
27	141227	HOUSING ASSEMBLY, Bearing	1
28	141228	SNAP RING	2
29	141229	CONE, Bearing	2
30	141230	SEAL, Bearing Oil	1
31 32		LOCKY 1/2 - 13 x 1-3/4" Hex. Hd.	1
33		WASHER, 1/2" Flat	3
34 35	141229 141230	CONE, Pulley Shaft Bearing	
36	141234	SEAL, Pulley Shaft Bearing Oil PULLEY, Drive (8" Dia.)	1
37	141235	PULLEY, Drive (8" Dia.)	1
38 39		NUT, 5/8" - 18 Hex. Slotted Pulley to Shaft	1
40	141678	V-BELT, Main Drive	
41	*142573	HOUSING ASSEMBLY, Belt (Includes Cup)	1
42	7W-4616	CUP. Bearing	
13	B-1202	CUP, Bearing	1
14	141308	SCREW ASSEMBLY, Belt Adjusting	1
		below:	1
5		NUT, 1/2" - 20 Hex. Jam	
6		NUT, 1/2" - 20 Hex. Jam - Adjusting Screw to Housing. SET SCREW, 1/2" - 20 x 3/4" Dog Point	1
	141305	SET SCREW, 1/2" - 20 x 3/4" Dog Point	1
	9N-750	CONE, Bearing	1
	141326	SEAL, Oil	1
	141327	WASHER, Flat	1
		NUT, 5/8" - 18 Hex. Slotted Flywheel Shoft to The	100
2 1	41328	COTTER PIN, 1/8" x 1	1
			1
		Consists of Flywheel which is not serviced separately plus Pitman Pin	1
1	41315	PIN, Pitman	
1	40415	BOX ASSEMBLY, Pitman	1
1	41317	BOX and BUSHING ASSEMBLY Ditmon	
1	41319	below: Bushing listed	
1	11019	BUSHING	

MODELS 14-1, 14-2, 14-9 and 14-10

FIG.	PART NO.	NAME AND DESCRIPTION	QTY. REQ.
		Group 1-1—MAIN DRIVE (Models 14-1, 14-2,	
		14-9, 14-10) (Cont'd)	
58	141323	SNAP RING	1
59	8M-1217	CUP, Bearing	1 1
60	/ / /	FITTING, Lube, 1/4" - 28 x 1/2" Str	1
61 62	8M-1216 141322	CONE, Bearing SEAL, Oil	1
63	8M-1217	CUP, Pitman Pin Bearing	1
64	8M-1216	CONE, Pitman Pin Bearing	1
65		WASHER 5/8" Flat	
66	HANNE	NUT, 5/8" - 18 Hex. Slotted Pitman Pin to Box	1
67	142186	COTTER PIN, 1/8" x 1-1/4"	1
68	141324	CAP ASSEMBLY, Pitman Dust	
69		FITTING, Lube, 1/8" - 27 x 3/4", Vented	1
70	141350	ARM and BALL ASSEMBLY, Pitman	1
		Consists of:	1
71	141351 141354	ARM, (Welded Assembly)	1
72	141354	Consists of Ball which is not serviced separately plus Nut listed	
73		NUT, 3/4" - 16 Hex	1
74	141397	PIN, Pitman	1
75 76		BOLT, 5/16" - 24 x 1-1/4" Hex. Hd. LOCKWASHER, 5/16"	2
	141241	DECAL, Caution	1
	68	*Part No. 142573 Belt Housing Assembly is effective with Serial No. 14-1-5487 and 14-2-5455.	The state of the s
		Part No. 141687 Belt Housing Assembly is no longer serviced. When replacing Belt Housing on units prior to Serial No. 14-1-5487 and after 14-1-1095 and on units prior to Serial No. 14-2-5455 and after 14-2-1062 order 142573 Belt Housing Assembly plus 1-141142 Pad, 1-5/8" - 18 x 3-1/2" Hex. Bolt, 1-5/8" - 18 Hex. Nut, 1-141305 Cone, 1-9N-750 Seal, 1-B-1202 Cup, and 1-141308 Screw Assembly.	
	141501 (1)	Part No. 141302 Belt Housing Assembly and Part No. 141870 Belt Housing and Dragbar Pin Assembly (Service Kit) are no longer serviced. When replacing Belt Housing on units prior to Serial No. 14-1-1095 and 14-2-1062 order 142573 Belt Housing Assembly plus 1-141683 Dragbar Anchor Pin Assembly, 1-141689 Washer, 1-7/8" Flat Washer, 1-7/8" - 14 Castle Nut, 1-1/8" x 1 Cotter Pin, 1-141142 Pad, 1-5/8" - 18 x 3-1/2" Hex. Bolt, 1-5/8" - 18 Hex. Nut, 1-141305 Cone, 1-9N-750 Seal, 1-B-1202 Cup, and 1-141308 Screw Assembly.	




FIG. PART NO. NAME AND DESCRIPTION

Fitting listed below:

LOCKWASHER, 5/8"

NUT, 5/8" - 18 Hex.

PIN, 3/8" x 1-7/8" Clevis

separately plus Nuts listed below:

COTTER PIN, 1/8" x 1

WASHER, 1/2" Flat

33A

		Group 1-6—PULL BAR, BALANCE SPRING, AND BREAK BACK HOUSING ASSEMBLIES (Cont'd)	14-1, 2	14-9, 10	14-15, 16
10	141605	HOUSING ASSEMBLY, Break Back	1	-	
11	LA (LEGIL)	Fitting listed below: FITTING, Lube, 1/4" - 28 x 25/32", 900	1	-	_
12	141607	PLUNGER, Break Back	1	-	-
13	141608	DISC, Break Back Plunger	1	-	_

MODELS 14-1, 14-2, 14-9, 14-10, 14-15 and 14-16

QTY. REQ.

Consists of Housing which is not serviced separately plus	1
Fitting listed below: FITTING, Lube, 1/4" - 28 x 25/32", 90°	1
PLUNGER, Break Back	1
DISC, Break Back Plunger	1
SPRING, Break Back	1
CAP, Break Back Adjusting	1

HOUSING ASSEMBLY, Break Back

FITTING, Lube, 1/4" - 28 x 25/32", 90°.....

PIN, Shoulder, 7/8" x 3-1/8".....

PLUNGER, Break Back.....

PIN, Clevis, 1/2" x 1-3/4" Bracket to Pull Bar.....

LINK, Tilt

LINK, Tilt

PIN, Clevis, .493 x 1.16, Tilt Link to Pull Bar Brkt.

PIN, Clevis......

COTTER PIN, 1/8" x 1", Tilt Link to Pull Bar Brkt.

ROD, Balance Spring End

CAP, Spring Retainer - Plain..........

U-BOLT, 3/8" - 16

CHAIN, 1/2" x 1, 29 Links.....

CLAMP ASSEMBLY, Cable

Consists of Brackets and U-Bolts which are not serviced

CABLE, 5/16" Dia. x 38"- Balance Spring

Balance Spring Assembly to

Consists of Housing which is not serviced separately plus




Figure 10 - Pull Bar, Balance Spring and Break Back Housing Assemblies

FIG.	PART NO	NAME AND DESCRIPTION		QTY. REQ.		
		Group 1-6—PULL BAR, BALANCE S AND BREAK BACK HO ASSEMBLIES (Cont'd)	USING	14-1,2	14-9, 10	14-15, 16
1	142675	PULL BAR (Welded Assembly)		_	_	1
-	141602	PULL BAR (Welded Assembly)		1	1	1
2	141615	TORE, Pull Bar (Welded Assembly).		1	1	
-	142775	TORE, Pull Bar (Welded Assembly)	S Seedle - V		•	1
3		NUI, 1-1/0 - 12 Jam - Pull Bar Yoke Retaining	r meneros e neriba la rappe di	1	1	1
-	142658	EYE ASSEMBLY, Pull Bar	,	1	1	1
5	141424	EYE ASSEMBLY, Pull Bar Consists of Eye which is not serviced separately plus Fitting listed below: FITTING, Lube, 1/4" - 28 x 1/2" Str.		1	1	1
6		BOLT, 1/2" - 20 x 2-11/16" Hex. Hd.	17.5.51 ±3	1	4	1
-	142677	SPACER, 1/2" I.D. x 1-1/4" O.D. x 1-1/2" Tube	D.11 D W.1	1	1	1
7	141618	SPACER, 1/2" I.D. x 1" O.D. x 1-1/2" Tube	- war Day I one	1	1	1
8		LOCKWASHER, 1/2"	to Eye	1	1	1
9		NUT, 1/2" - 20 Hex.		1	1	1